

Operating Manual Addendum

For Systems Which Accept Standard Compact Discs

Specially ordered Chime Master systems will accept standard compact discs in magazine trays 1 through 6 (the top magazine of the Model Twelve). Note that tray 1 must contain a disc with the clock striking functions on it for the clock to strike automatically. Discs with clock striking functions are CMS1111, CMS1112 (clock strikes the Chime) and CMS2113 (clock strikes the Cast Bell Carillon).

Selection Numbers for Standard Discs

The first two digits of the selection number will represent the magazine tray number holding the disc (with a mandatory leading zero). The second two digits represent the track number. For example, to play track 9 of the disc installed in tray 3, enter 0309.

Selections from standard discs will not be included in the random music programs.

Model Six Standard Disc Usage

Typically standard discs contain program material inappropriate for broadcast from the tower speakers. Although you could program the system to play selections from standard discs automatically, you must manually turn the tower speakers off. We recommend that you program standard discs to play only on the remote function buttons, or the manual mode.

When you are finished using the standard discs, they should be removed, and the function button programs that play them should be cleared.

Model Twelve Standard Disc Usage

The Chime Master model Twelve carillon is equipped with three audio output jacks on the rear panel. Standard disc audio programs are output through the top (Standard Program) and bottom (PA Output) jacks. Chime Master disc audio program is output through the middle (Tower Output) and bottom (PA Output) jacks. There is no need to manually turn the tower speakers off when playing standard discs.



Compact Disc *Carillon*

Chime Master Systems
P.O. Box 936
Lancaster OH 43130

1-800-344-7464